

### Canadian Bioinformatics Workshops

www.bioinformatics.ca

#### This page is available in the following languages:

Afrikaans български Català Dansk Deutsch Еλληνικά English (CA) English (GB) English (US) Esperanto Castellano (AR) Español (CL) Castellano (CO) Español (Ecuador) Castellano (MX) Castellano (PE) Euskara Suomeksi français français (CA) Galego איביי hrvatski Magyar Italiano 日本語 한국어 Macedonian Melayu Nederlands Norsk Sesotho sa Leboa polski Portuguës română slovenski jezik српски srpski (lalinica) Sotho svenska 中文 季語 (台灣) isiZulu



#### Attribution-Share Alike 2.5 Canada

#### You are free:



to Share - to copy, distribute and transmit the work



to Remix - to adapt the work



#### Under the following conditions:



Attribution. You must attribute the work in the manner specified by the author or licensor (but not in any way that suggests that they endorse you or your use of the work).



Share Alike. If you alter, transform, or build upon this work, you may distribute the resulting work only under the same or similar licence to this one.

- . For any reuse or distribution, you must make clear to others the licence terms of this work.
- · Any of the above conditions can be waived if you get permission from the copyright holder.
- The author's moral rights are retained in this licence.

Disclaime

Your fair dealing and other rights are in no way affected by the above.


This is a human-readable summary of the Legal Code (the full licence) available in the following languages:

English French

## RNA-Seq Module 4 Isoform Discovery and Alternative Expression (tutorial)

Malachi Griffith, Obi Griffith, Fouad Yousif High-Throughput Biology: From Sequence to Networks March 20-26, 2017







### **Learning Objectives of Tutorial**

- Learn how to run StringTie in 'reference only', 'reference guided', and 'de novo' modes
- Learn how to use Cuffmerge to combine transcriptomes from multiple Cufflinks runs and compare assembled transcripts to known transcripts
- Learn how to perform differential splicing analysis with Ballgown
- Examine junctions counts with RegTools and StringTie alternative transcript files at the command line
- Visualize junction counts and StringTie assembled transcripts in IGV

## 5-i,ii. Running stringtie in 'ref-guided' and 'de-novo' mode

- In Module 3 we ran StringTie in 'ref-only' mode. This mode gives us an expression estimate for each known gene/transcript
- Now we want to be able to potentially identify novel genes, and novel isoforms of known genes
- To accomplish this we will re-run cufflinks in 'ref-guided' and 'de-novo' modes
  - In 'ref-guided' mode a known transcriptome will be used as a guide
  - In 'de-novo' mode no knowledge of the transcriptome will be used at all

## Options that govern use of existing transcript information

- During indexing of the genome with hisat2, transcript information is provided
  - A transcriptome GTF file is used to extract splice sites and exons
  - These are supplied during the index step to build a better index
  - These will be used to assist the alignment step by allowing alignment to both transcriptome and genome sequences
  - Coordinates from alignments to transcriptomes will be converted back to genome coordinates
  - Even though we supply transcriptome info, hisat2 will not be limited in to known transcripts or splice sites
- Stringtie '-G' option
  - Used to supply a transcriptome GTF file
  - If specified, uses the reference annotation file (in GTF or GFF3 format) to guide the assembly process. We call this the 'ref-guided' analysis mode
- Stringtie '-e' option
  - Limits the processing of read alignments to <u>only</u> estimate and output the assembled transcripts matching the reference transcripts given with the -G option
  - We call this 'reference-only' analysis mode
- Running StringTie with neither '-G' or '-e'
  - We call this 'de-novo' analysis mode


### A 'junctions.bed' file

- After alignment, we can create a summary of all reads that support exon-exon junctions
  - e.g. exon1-exon2 has 5 reads
  - e.g. exon1-exon3 has 9 reads
- This file reports all of the unique exon-exon junctions observed and the read counts for each
  - In BED format

```
track name=junctions description="TopHat junctions"
22
        17062079
                         17063415
                                           JUNC00000001
                                                                             17062079
                                                                                              17063415
                                                                                                                255,0,0 2
                                                                                                                                         0,1317
22
        17092740
                         17095057
                                           JUNC000000002
                                                                             17092740
                                                                                              17095057
                                                                                                                255,0,0 2
                                                                                                                                 43,91
                                                                                                                                          0.2226
22
        17117940
                         17119543
                                           JUNC000000003
                                                                             17117940
                                                                                              17119543
                                                                                                                255,0,0 2
                                                                                                                                 40,75
                                                                                                                                         0,1528
22
        17152466
                         17156100
                                           JUNC000000004
                                                                             17152466
                                                                                              17156100
                                                                                                                255,0,0 2
                                                                                                                                 12,88
                                                                                                                                         0,3546
22
        17525819
                         17528242
                                                                                                                255,0,0 2
                                           JUNC000000005
                                                                             17525819
                                                                                              17528242
                                                                                                                                 71,29
                                                                                                                                          0,2394
22
        17528261
                         17538007
                                                                             17528261
                                                                                              17538007
                                                                                                                255,0,0 2
                                                                                                                                 55,45
                                           JUNC00000006
                                                                                                                                         0,9701
22
        17566071
                         17577976
                                           JUNC000000007
                                                                             17566071
                                                                                              17577976
                                                                                                                255,0,0 2
                                                                                                                                 48,25
                                                                                                                                          0,11880
22
        17577951
                         17578785
                                           JUNC00000008
                                                            24
                                                                             17577951
                                                                                              17578785
                                                                                                                255,0,0 2
                                                                                                                                         0,735
                                           JUNC00000009
        17578093
                         17578710
                                                                             17578093
                                                                                              17578710
                                                                                                                255,0,0 2
                                                                                                                                          0,593
```

Junction read count

### Viewing the junctions.bed in IGV




### 5-iii,iv. Cuffmerge


http://cufflinks.cbcb.umd.edu/manual.html#cuffmerge

- Cuffmerge combines transcripts predicted from multiple RNA-seq data sets into one view of the transcriptome
  - Do this before running cuffdiff to compare between multiple conditions
- Cuffmerge can also simultaneously compare transcripts to the known transcripts GTF file from Ensembl, etc.
  - http://cufflinks.cbcb.umd.edu/manual.html#class\_codes

## 5-v. Comparison of merged GTFs from each StringTie mode



## Comparison of merged GTFs from each StringTie mode



# We are on a Coffee Break & Networking Session